

■舞台照明設備 負荷回路表

DMX No.	負荷名称	調光機 No.	DMX No.	負荷名称	調光機 No.	DMX No.	負荷名称	調光機 No.	DMX No.	負荷名称	調光機 No.	DMX No.	負荷名称	調光機 No.
1	1S-1	1	26	UH-2	26	51	2FR上-3	39	76	SC上-5	76	101	1B-1 #W	LED
2	1S-2	2	27	UH-3	27	52	2FR下-1	40	77	SC上-6	77	102	1B-2 #72	LED
3	1S-3	3	28	UH-4	28	53	2FR下-2	41	78	SC下-1	78	103	1B-3 #78	LED
4	1S-4	4	29	UH-5	29	54	2FR下-3	42	79	SC下-2	79	104	1B-4 #W	LED
5	1S-5	5	30	UH-6	30	55	3FR上-1	43	80	SC下-3	80	105	2B-1 #W	LED
6	1S-6	6	31	UH-7	31	56	3FR上-2	44	81	SC下-4	81	106	2B-2 #72	LED
7	1S-7	7	32	UH-8	32	57	3FR上-3	45	82	SC下-5	82	107	2B-3 #78	LED
8	1S-8	8	33	UH-9	33	58	3FR上-4	46	83	SC下-6	83	108	2B-4 #W	LED
9	1S-9	9	34	UH-10	34	59	3FR下-1	47	84	後C-1	84			
10	1S-10	10	35	UH-11	35	60	3FR下-2	48	85	後C-2	85	110	天反-1	LED
11	1S-11	11	36	UH-12	36	61	3FR下-3	49	86	後C-3	86	111	天反-2	LED
12	1S-12	12	37	LH-上-1	51	62	3FR下-4	50	87	溝C-1	87	112	天反-3	LED
13	2S-1	13	38	LH-上-2	52	63	CL-1	63	88	溝C-2	88	113	天反-4	LED
14	2S-2	14	39	LH-上-3	53	64	CL-2	64	89	溝C-3	89			
15	2S-3	15	40	LH-上-4	54	65	CL-3	65	90	溝C-4	90	120	客席-1	LED
16	2S-4	16	41	LH-中-1	55	66	CL-4	66	91	溝C-5	91	121	客席-2	LED
17	2S-5	17	42	LH-中-2	56	67	CL-5	67	92	溝C-6	92	122	客席-3	LED
18	2S-6	18	43	LH-中-3	57	68	CL-6	68	93	前C	93	123	客席-4	LED
19	2S-7	19	44	LH-中-4	58	69	CL-7	69	94	袖W上-1	94	124	客席-5	LED
20	2S-8	20	45	LH-下-1	59	70	CL-8	70	95	袖W上-2	95	125	親子室	LED
21	2S-9	21	46	LH-下-2	60	71	CL-9	71	96	袖W上-3	96	126	客席-6	LED
22	2S-10	22	47	LH-下-3	61	72	SC上-1	72	97	袖W下-1	97	127	客席-7	LED
23	2S-11	23	48	LH-下-4	62	73	SC上-2	73	98	袖W下-2	98			
24	2S-12	24	49	2FR上-1	37	74	SC上-3	74	99	袖W下-3	99			
25	UH-1	25	50	2FR上-2	38	75	SC上-4	75	100	予備	100			

直回路⇔調光回路 切替可能

※1B / 2B / 天反 は直回路を使用
(常設状態において1B-①/2B-①/天反①②を使用)

舞台作業灯	1B-1 / 2B-1
客席作業灯	客席-1~7